# Preview Display

TENSION FABRIC FRAMES

Installation Guide

150mm Free Standing Frame

Your Kit Contains:


2x Vertical frame struts

2x Horizontal frame struts

8x L-shaped corner brackets

32x M6 Grub screws for corner brackets


1 Vertical Brace (On frames 3 meters or more wide)

2/3 feet depending on width with M6 screws.

How To Assemble:

1 Begin by fastening the 'L' brackets into the bottom piece of frame using the supplied grub screws and an M6 Allen Key. (Fig. 1)

2 Next, slide the verticals onto the L brackets, and secure the grub screws.

(Fig. 1) 'L' bracket and aluminium profile

3 For the Top of the frame, secure the L brackets first, before slotting the top bar with brackets into the tracks, then tighten to secure the frame. (Fig. 2)

4 Remember to fit the mid-brace/s if your frame is 3000mm or more in width. These help to give stability to the frame.

5 Finally, screw the feet into the base of the frame, using the supplied M6 bolts.

(Fig. 2) Exploded View of Tension Fabric Frame

Installing Graphics:

1 First, insert the PVC edging of the graphic into the top left and right hand corners of the frame.

2 Next, insert the very middle of the top of the graphic into the track, to hold the top edge in place.

3 After this, attach the bottom left and right hand corners into the PVC track.

4 Attach the middle part of the bottom graphic.

5 Insert the middle parts of the vertical edges of the fabric.

6 Secure the loose edges on the left and right sides of the frame.

7 Finally, insert the remaining PVC on the top and bottom edges of the frame, which will pull the graphic tight.

(Fig. 4) Graphic Fitting Diagram